



# STREET SCENE EQUIPMENT, INC.

**950-70140**  
**1995 - 2004**  
**CHEVY ASTRO VAN**  
**HOLEY ROLLIE**  
**ROLL PAN**  
**URETHANE**

## INSTALLATION INSTRUCTIONS

**NOTE:** Fit all parts before painting ( See Special Instructions For Paint Prep. ) Parts that have been installed, preped, or painted are not returnable.

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Rear Roll Pan	1	Instruction Sheet	1	Street Scene Decal
20	1/8" Pop Rivets	1	Urethane Prep Sheet	25 FT.	1/2" Double Sided Tape

TOOL LIST
1/8" Drill Bit, Drill Motor

1. Temporarily install the Street Scene Rear Valance and note areas that lay against the body. These are the areas that you will apply the double - sided tape. Before you allow the double sided tape to contact the body make sure that all area's are clean. NOTE: Installation of the rear valance requires the help of another person or the use of well placed c-clamps to hold the valance in place.
2. The rear valance wraps into each rear wheel well and has a lip flange that mates onto the rear doorsill.
3. Double-sided tape is applied along the side of the rear valance and along the rear lip flange. Drill and install 2 rivets in each fender well and several equally spaced rivets along the rear doorsill ensuring that they are not readily seen with the doors closed.
4. Paint to match making sure to follow the urethane painting procedure.

Photo 1



**NOTE: USE INTERCOOLED EXHAUST TIPS ONLY**