



STREET SCENE EQUIPMENT, INC.

950-70143
1999-2002
SILVERADO
2000-2004
SUBURBAN & TAHOE
BUMPER COVER
/ VALANCE
GENERATION 4

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Bumper Cover	1	Instruction Sheet	1	Street Scene Decal
4	S/S Screws	1	Urethane Prep Sheet		
6 FT.	3/4" Two Sided Tape	2	Tie - Wraps		

TOOL LIST
Phillips Screwdriver, Drill Motor, Drill Bits

1. Remove the factory lower valance.
2. If your vehicle has factory fog / driving lights remove them & zip tie the wires to keep them out of the way. **NOTE:** Your factory fog / lights will no longer be connected.
3. Clean the upper cap on bumper with a suitable cleaner to promote adhesion of tape.
4. Clean the top underside of bumper cover as you did to the upper cap.
5. Apply the two sided tape to the underside of the S/S Bumper Cover. Leave the backing on at this time.
6. Place the bumper cover over the front bumper.
7. Drill two holes on each side through bumper cover and into the steel bumper. Install the screws provided.
8. Remove the backing from the two sided tape and apply pressure to adhere the tape.