



STREET SCENE EQUIPMENT, INC.

**950-70160
GMC ENVOY
2002 - 2004
SIDE SKIRTS**

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See special instructions for paint Prep.) Parts that have been installed, prepped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	RH Skirt	1	Urethane Prep. Sheet	14 FT.	1/2" Two Sided Tape
1	LH Skirt	1	Street Scene Decal	6	Black Washer Head Screws
1	Instruction Sheet				

TOOL LIST	
Phillips Screwdriver	

**NOTE:
PRE-FIT BEFORE PAINTING**

1. Set the side skirt to vehicle (Shirts are marked on back side for location). Identify the area on the cab that the two sided tape will adhere too and clean properly.
2. Clean the back side of skirt and apply the two sided tape, **DO NOT** remove the backing on the tape at this time. Remember you can not " **OVER CLEAN** " the area.
3. Set the skirt on the vehicle and lift one end of backing and pull away from tape while pressing skirt against body.
4. At front wheel well opening install two screws thru skirt and into fender lip.
5. At rear wheel opening install one screw thru skirt and into fender lip.

**NOTE:
OTHER STREET SCENE ENVOY BODY ENHANCEMENT KITS**

**FRONT VALANCE PART # 950-70161
REAR SKIRT KIT PART # 950-70162**