



STREET SCENE EQUIPMENT, INC.

**950-70162
GMC ENVOY
2002 - 2004
REAR SKIRT KIT**

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See special instructions for paint Prep.) Parts that have been installed, prepped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Instruction Sheet	1	Urethane Prep. Sheet	1	RH Side Rear Skirt
1	Street Scene Decal			1	LH Side Rear Skirt
6	Black Washer Head Screws			10 FT.	1/2" Wide 2 Sided Tape

TOOL LIST	
Phillips Screwdriver	

NOTE: PRE-FIT BEFORE PAINTING

1. Clean the inside flange of rear skirt and apply the two sided tape. DO NOT remove the backing at this time.
2. Set the skirt against body and take note of the contact area. Remove SKIRT and clean the area well.
3. Set the skirt against the body and lift one corner of backing and pull away while pressing skirt against body.
4. From inside of wheel well opening, install two screws thru valance and into fender lip. Install a third screw from the under side approximately one foot from the end at the back of the vehicle. Do the same on the opposite side.

NOTE: OTHER STREET SCENE BODY ENHANCEMENT KITS

**SIDE SKIRT KIT PART # 950-70160
FRONT VALANCE PART # 950-70161**