



# STREET SCENE EQUIPMENT, INC.

**950-70165**  
**1988 - 1998**  
**GM CK**  
**1992 - 1999**  
**SUBURBAN / TAHOE**  
**FRONT BUMPER COVER**  
**GENERATION 7**

## INSTALLATION INSTRUCTIONS

**NOTE: Fit all parts before painting ( See special instructions for paint Prep. ) Parts that have been installed, prepped, or painted are not returnable.**

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

### DRILLING NECESSARY

PARTS LIST					
1	Bumper Cover	1	Instruction Sheet	1	Street Scene Decal
4	Stainless Steel Screws	6 FT.	3/4" Two Sided Tape	1	Urethane Prep. Sheet

TOOL LIST
3/8" Ratchet, 3/8" 3" Extension, 10MM Wrench, 10MM Socket, 5/64" Drill Bit, Drill Motor, Safety Glasses

1. Before beginning installation be sure to wear proper eye protection.
2. Remove the license plate holder from the front bumper, if so equipped, by removing the 4 bolts and nuts attaching it to the bumper. **NOTE:** you will not be to re-install this on the bumper cover. If a front license plate has to be retained, go no further.
3. Remove the eleven 10 MM head screws from the under side of the bumper securing the air deflector to the front bumper.
4. Remove the impact strip from the front bumper by removing the 10 MM nuts at the right and left inside corners of the bumper.
5. Grasp the impact strip and pull to remove.
6. Starting at one corner, slip the bumper cover over the bumper and gently pull to the opposite side and snap over the bumper.
7. Drill two holes on each end into bumper in wheel well area. Attach with screws provided.
8. Paint to match. Follow urethane parts surface preparation procedures.