



STREET SCENE EQUIPMENT, INC.

950-70168
GM ASTRO / SAFARI
SIDE SKIRTS
2 PIECE SET
1985 - 1994

INSTALLATION INSTRUCTIONS

WE HIGHLY URGE THAT INSTALLATION BY A PROFESSIONAL BODY SHOP

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1 Pr.	Street Scene Side Skirts	1	Instruction Sheet	1	Urethane Prep. Sheet
25 FT.	Double Sided Tape	20	1/8" Pop Rivets		

TOOL LIST	
Drill Motor, Drill Bits, Assorted Hand Tools, Pop Rivet Gun	

1. Temporarily install the Street Scene side skirts and make note of all the areas on the inside of the side skirt that rest along the body, These are the areas that you will apply the double - sided tape. With the exception of the door sill portion of the skirt clean and apply double sided tape to the inside of the skirt and with the aid of a friend install the skirt.
2. Install rivets in the front of the skirt behind the front wheel, the doorsill where the skirt folds under the door (3 equally spaced rivets) and the back of the skirt of the rear wheel (2 rivets) with respect to the doorsill install the rivets in an area that will not be seen with the door closed.