



STREET SCENE EQUIPMENT, INC.

950-70187
2000 - 2004
CHEV GMC TAHOE
& YUKON 4 DOOR
SIDE SKIRT KIT 4 PC

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
12 FT.	1/2" Two Sided Tape	1	Instruction Sheet	1	Street Scene Decal
30	1/8" Pop Rivets	1	Urethane Prep Sheet		
1	RH Cab Side Skirt	1	RH Corner Skirt		
1	LH Cab Side Skirt	1	LH Corner Skirt		

TOOL LIST
Drill Motor, 1/8" Drill Bit, Masking Tape,

CAB SKIRTS

1. Open doors and set the cab skirts to body to the approximate mounting area. Clean the body section where the two sided tape will be applied to. Do the same to the side skirts.
2. Apply the two sided tape to the top edge of side skirt and set the side skirt against the body. Position and drill four or five 1/8" holes along the top edge of flange in an area not seen with the doors closed and secure with pop rivets.
3. Drill and rivet the front and rear of the skirt to the wheel wells.

CORNER SKIRTS

1. Install the corner skirts on the body and mark the areas that will lay against the body. Once in place mark the sides of the body so that you will know where the parts fit.
2. Using the markings on the sides, rough up the paint on the corner skirts in the area hidden from view with sandpaper and then clean it with wax and grease remover. Also clean the area that will be applied to the body.
3. Apply the corner skirts to the body following marks made previously. Drill 1/8" holes and install rivets in the rear fender where the corner skirts fold into the wheel well and underneath the corner skirts.