



## **INSTALLATION INSTRUCTIONS**

**VERY IMPORTANT!** Read and understand all directions and check the following parts list before starting installation.

<b>PARTS LIST</b>					
<b>1</b>	WIPER COWL	<b>1</b>	Instruction Sheet	<b>1</b>	Paint Preparation Sheet

<b>TOOL LIST</b>	
Flat Head Screw Driver, 13MM Socket, Racket	

1. Open hood and remove . Set aside carefully.
2. Disconnect the windshield washer hoses from the wiper arms.
3. Remove the black nut cover over the wiper arm attaching nuts with a flat blade screw drive and remove the 13mm nuts securing the wiper arms.
4. Lift the wiper arms from the windshield and gently pry arm from the shaft. Note the position of the arm in reference to the hood cowl. Also note: There are right and left wiper arms. They are marked on the inside of the wiper arms.
5. Gently pry off the right and left of the OEM hood cowl with a flat head screw driver.
6. Remove the 4 push-on clips on the front end of the hood cowl. Set aside for installing the new hood cowl.
7. Lift up the drivers side of hood cowl slightly and disconnect the washer line.
8. Remove the hood cowl by lifting the passanger side up first and than lifting the driver side up and out.
9. Remove the windshield washer hose and the seal on the oem hood cowl. It will be necessary to first remove the hose elbows from the grommets.
10. Install the windshield washer hose the provided hood cowl and than install hose elbows.
11. Wipe off the back side of the hood seal and install the provided double sided tape. Trim to fit. Install hood seal to the hood cowl at the approximate location of OEM hood cowl. You will need to swap over the rear seal as well.
12. Install the hood cowl on the truck by first by installing the the driver side over the wiper arm shaft and following with the left side.
13. Reconnect washer hose to tee. Make sure washer hose is resting in the tunnel of the hood cowl.
14. Re-install the four clips removed on the front edge of the hood cowl. Install the 2 clips provided on the right and left sides of the hood cowl.
15. Install wiper arms in their proper position and locations and secure with nuts and nut covers. Reconnect washer hoses to wiper arms.
16. Re-install and close the hood and test the fit of the hood cowl and test the wipers and washers.