



STREET SCENE EQUIPMENT, INC.

950-70198
2007
CHEVY SILVERADO
BUMPER COVER GEN 1
URETHANE

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

NOTE:

Check fit all body parts PRIOR to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

NOTE:

The Street Scene bumper cover will fit trucks with or without factory fog lamps.

PARTS LIST					
1	Bumper Cover	1	Instruction Sheet	4 FT.	3/4" Two Sided Tape
		1	Urethane Prep Sheet	1	Street Scene Decal

TOOL LIST
Drill Motor, 3/16" Drill Bit, Alcohol

1. Turn the front wheels right and left to expose the screws securing the inner fenders to the corners of the front bumper. Remove screws and save. If equipped with fog lamps reach in and unplug the wire harness.
2. Remove the right and left ABS ends on bumper.
3. Remove the ABS lower section of bumper.
4. Remove the fog lamps from the sides.
5. Install the fog lamps into the Street Scene bumper cover. Rotate lamp 90 degrees to install.
6. If your vehicle does not have fog lamps they may be purchased from your local GM parts supplier use part numbers 15938290 for the right side and P.N. 15938289 for the left side. The lamps each come with the three plastic retainers needed for installation. If your vehicle does not have the wiring in the system you can purchase the pig tail connector P.N. 19168034 from your local GM dealer and wire in the lamps. Always use a relay and fuse in system. If you wish not to have fog lamps cut off back mounting flange in the bumper cover to create an air duct.
7. Clean off the top of the chrome bumper with alcohol and apply the two sided tape on it.
8. Wipe the underside of bumper cover with alcohol were it will contact the tape.
9. Install the bumper cover on vehicle. Once you are sure that it is centered and located properly, Remove backing on tape and apply pressure on the top side of bumper cover over the tape.
10. Connect fog lamp wire harness. The harness can be pulled slightly to lengthen.
11. Drill holes in edge of bumper cover and attach the inner fenders with the OEM hardware removed in step one.