



# STREET SCENE EQUIPMENT, INC.

950-70206  
1998 - 2004  
CHEV S-10  
FRONT VALANCE

## INSTALLATION INSTRUCTIONS

**NOTE:** Fit all parts before painting ( See Special Instructions For Paint Prep. ) Parts that have been installed, preped, or painted are not returnable.

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Street Scene Valance	1	Instruction Sheet	1	Street Scene Emblem

TOOL LIST	
Drill Motor, 1/4" Drill Bit, Ratchet, Metric Sockets	

1. Remove the OEM valance from bumper. Save all attaching hardware.
2. Set the OEM valance on to the Street Scene valance, Mounting side to mounting side and mark mounting holes. Drill holes with a 1/4" drill bit.
3. Attach with bolts removed in step 1.