## STREET SCENE EQUIPMENT, INC.



950-70310 1992 - 1995 TOYOTA PICKUP FRONT VALANCE

## INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting ( See Special Instructions For Paint Prep. ) Parts that have been installed, preped, or painted are not returnable.

**VERY IMPORTANT!** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST						
1	Street Scene Valance	1	Instruction Sheet			
				1	Paint Preperation Sheet	

TOOL LIST	
NONE	

- 1. Remove the front valance from beneath the bumper.
- 2. Re-use the clips on the Street Scene Valance and install.

STREET SCENE BODY KITS CAR BODY KITS