



**STREET SCENE EQUIPMENT, INC.**

**950-70318**  
**2003-2007**  
**NISSAN 350Z**  
**FRONT FASCIA**  
**URETHANE**

### **INSTALLATION INSTRUCTIONS**

**NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.**

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

<b>PARTS LIST</b>					
<b>1</b>	Rear Valance	<b>1</b>	Instruction Sheet	<b>1</b>	Urethane Prep Sheet
<b>14</b>	Push-in Fastener(18378)				

<b>TOOL LIST</b>	
Drill Motor, Assorted sockets and wrenches, Sandpaper/scotch brite	

1. Start by removing the clips on the topside of the front fascia (**FIG.1**)
2. Remove the screws that join the front fascia fender well cover (**FIG.2**)
3. Next you will need to remove the various screws on the underside of the vehicle holding on the splash guard. (**FIG.3**)
4. Reinstall the new fascia onto the vehicle as the stock fascia was removed. You will need to drill out the indentations that mark the guide holes first.

**NOTE: IF YOU OWN 2003-2006 Z YOU CAN REUSE ALL OF YOUR STOCK HARDWARE. IF YOU OWN A 2007+ Z YOU WILL NEED TO USE THE PROVIDED SCREWS FOR ATTACHING THE BUTTON OF THE FASCIA TO THE SPLASH GUARD. BE SURE TO MAKE PILOT HOLES BEFORE USING THE SELF-TAPPING SCREWS.**

5. Done! Enjoy the looks of your new Street Scene front fascia.

