STREET SCENE EQUIPMENT, INC.



## INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Bumper Cover	1	Instruction Sheet	4	S/S Phillips Head Screws
		1	Urethane Prep Sheet	1	Street Scene Decal
7311 1007					

5/64" Drill Bit, Phillips Screwdriver

## NOTE Pre- Fit Bumper Cover Prior TO Painting

- 1. If vehicle is equipped with a chin spoiler remove before installing bumper cover.
- 2. Install the bumper cover from one side, then working your way to the other side. Drill two holes per side through the rear flange of bumper cover and into the front bumper. Attach with screws provided. If bumper flexs upward in center when tightening screws install washers between cover and bumper as needed to keep bumper cover flat across the top.