



STREET SCENE EQUIPMENT,INC.

950-70502
1994 - 2001
DODGE RAM
BUMPER COVER

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See special instructions for paint Prep.) Parts that have been installed, prepped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

DRILLING NECESSARY

PARTS LIST					
1	Bumper Cover	1	Instruction Sheet	1	Street Scene Decal

TOOL LIST	
Drill Motor, Safety Glasses, 1/4" Drill Bit, 3/8" Ratchet, 3/8" 6" Extension, 3/8" # 25 Torx Socket	

1. Before beginning installation be sure to wear proper eye protection.
2. Remove the # 25 Torx head screws securing the air deflector to the front bumper. Save all hardware.
3. Starting at one corner, slip th bumper cover over the bumper and gently pull to the opposite side and snap over the bumper.
4. Drill with the 1/4" drill bit through the bumper cover and into the holes in the bumper where the air deflector was removed.
5. Re-install the air deflector over the bumper cover and attach with the bolts removed in step 2.
6. Paint to match. Follow fiberglass parts surface preparation procedures.