



STREET SCENE EQUIPMENT, INC.

950-70507
2006 - 2008
DODGE RAM
BUMPER COVER
GENERATION 1

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation. Make sure you test fit bumper cover before painting!!!!

PARTS LIST					
1	Bumper Cover	1	Instruction Sheet	1	Urethane Paint Prep. Sheet

TOOL LIST	
8MM Torx Socket	

1. Start by taking off the black factory air defelctor attached to the bottom of the bumper.
2. You will use the 3 factory screws off of the inside part of the wheel well to attach the Street Scene bumper.
3. Starting at one side slide the bumper cover over the bumper and then pull it across over the other side.
4. Attach the bumper by screwing it on with the 3 screws taken off of each side on the inside part of the wheel well.