



STREET SCENE EQUIPMENT, INC.

950-70590
1987 - 1993
DODGE D-50
FRONT VALANCE

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Street Scene Valance	1	Instruction Sheet		
16	1/4" Flat Washers	8	1/4-20 X 3/4" Bolts	8	1/4-20 Nyloc Nuts

TOOL LIST	
Ratchet, 7/16" Wrench, Drill Motor, 1/4" Drill Bit	

1. Remove the OEM valance from truck.
2. Place the OEM valance and Street Scene valance mounting sides face to face.
3. Mark the hole location and drill a 1/4" hole.
4. Fasten the Street Scene valance with the screws provided.