



STREET SCENE EQUIPMENT, INC.

950-70720
1997 - 2003
FORD F-150 STYLE SIDE
SMOOTH BED CAP
2 PC. SET

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1 PR.	Smooth Bed Caps	1	Instruction Sheet	1	Street Scene Decal
25FT.	1/2" 2 Sided Tape	1	Urethane Prep Sheet		

TOOL LIST
NONE REQUIRED

NOTE:

This kit requires supplement kit for tailgate. Use Part # 950-70721 for smooth tailgate cap, Check fitment of Bed Caps before painting, Follow urethane painting instructions.

1. Remove the factory bed rail protectors. Clean the area with alcohol.
2. Clean the back side of the smooth bed caps with alcohol at the areas that the two sided tape will be applied.
3. Apply the two sided tape to the smooth bed caps on the outward edges leave the backing on.
4. Set the smooth bed caps into position lift the corner of the backing of the two sided tape and pull off while applying pressure to the caps against the bed.