



STREET SCENE EQUIPMENT, INC.

950-70726
2001 - 2003
FORD F-150 SUPER CREW
SMOOTH TAILGATE CAP

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Smooth Tailgate Cover	1	Instruction Sheet		
10FT.	1/2" 2 Sided Tape	1	Urethane Prep Sheet	1	Street Scene Decal

TOOL LIST	
NONE	

NOTE:

Check fitment of tailgate cap before painting, Sand edges to match tailgate width. Follow urethane painting instructions.

1. Remove factory tail gate piece. Clean top edge of tailgate with alcohol.
2. Clean the back side of the smooth tailgate cap with alcohol and apply the two sided tape.
3. Set the smooth tailgate cap into position and remove the two sided tape while applying pressure to the part.