



# STREET SCENE EQUIPMENT,INC.

**950-70727**  
**1999 - 2004**  
**CHEVY SILVERADO**  
**&**  
**GMC SIERRA**  
**SMOOTH BED CAPS**

## INSTALLATION INSTRUCTIONS

**NOTE: Fit all parts before painting ( See Special Instructions For Paint Prep. ) Parts that have been installed, preped, or painted are not returnable.**

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
<b>1 PR.</b>	Smooth Bed Caps	<b>1</b>	Instruction Sheet	<b>1</b>	Street Scene Decal
<b>27 FT.</b>	1/2" 2 Sided Tape	<b>1</b>	Urethane Prep Sheet		

TOOL LIST
NONE REQUIRED

1. Clean the factory bed rail with alcohol.
2. Clean the back side of the smooth bed caps with alcohol at the areas that the two sided tape will be applied.
3. Apply the two sided tape to the smooth bed caps on the outward edges leave the backing on.
4. Set the smooth bed caps into position starting at the tailgate end. lift the corner of the backing of the two sided tape and pull off while applying pressure to the caps against the bed.