



INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Left Side Louver	1	Instruction Sheet	8 FT.	1/2" Two Sided Tape
1	Right Side Louver	1	Urethane Prep Sheet	1	Street Scene Decal
				2 PKGS	3M Adhesion Promoter

TOOL LIST	
Sand Paper, Adhesive Promoter	

1. Thoroughly clean both sides of the louver set.
2. Please find the tape line extending around the perimeter of the back side of each louver. Scuff this surface and apply adhesive promoter. Install strips of double sided mounting tape in the areas indicated. (Image I)

Image I



3. Thoroughly clean the rear side windows of all debris, dust and wax.
4. Remove, red plastic backing tape and adhere louvers to rear windows. (Image II)

Image II



Special NOTE: These products are manufactured in tough, durable polyurethane. Please follow paint suppliers prep and paint instructions to insure proper paint adherence. It is recommended to paint the inside of the cover flat black and the outside to match the vehicle. The inside of the louver can be seen thru the window, from the inside of the car.