



STREET SCENE EQUIPMENT, INC.

950-70762
2005 - 2008
FORD MUSTANG V-6 CYL.
FRONT CHIN SPOILER

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

NOTE:

Check fit all body parts PRIOR to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PROPER CLEANING IS A MUST FOR GOOD ADHESION. WIPE ADHESION PROMOTER ON BODY AT MOUNTING STRIP.

PARTS LIST					
1	Front Chin Spoiler	1	Instruction Sheet	2	Adhesive Promoter
1	Street Scene Decal	1	Urethane Prep Sheet	8 FT	1/2" Wide Two Sided Tape

TOOL LIST
Drill Motor, 3/16" Drill Bit, Phillips Screwdriver

1. Clean the back side of spoiler where it will contact body with an non - oil base cleaning solvent. Wipe the strip with the adhesive promoter. Apply the two sided tape but DO NOT remove the backing at this time.
2. Remove the two phillips head screws at the bottom of the inner fenders.
3. Set the spoiler to front of vehicle. The center top lip should lay on the ledge of the opening. Drill two 3/16" holes in the spoiler to match with the holes in inner fenders.
4. Attach spoiler ends using the screws removed in step 2. Remove the tape backing and secure spoiler to body buy applying pressure over the tape edge.