



STREET SCENE EQUIPMENT, INC.

950-70768
2005 - 2008
FORD MUSTANG
SIDE SKIRT KIT 4 PC
GENERATION 3

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, prepped, or painted are not returnable.

NOTE:

Check fit all body parts PRIOR to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Side Skirt Kit 4 PC	1	Instruction Sheet	16 FT	1/2" Wide Double Sided Tape
1	Street Scene Decal	1	Urethane Prep Sheet	10	# 8 Washer Head Screws
2PGK	Adhesion Promoter				

TOOL LIST
Drill Motor, 1/8" Drill Bit

Pre-fit all pieces to the vehicle. Once you are assured you have the right body styling kit you may proceed. If uncertain call SSE to double check part number with your application. We highly recommend using masking tape anywhere the body kit will be touching the vehicle body to prevent scratches during pre-fit. Do any sanding, filing, or spacing necessary (BEFORE PAINTING) for a clean tight fit.

NOTE: Parts that have been drilled, installed, or painted are not returnable.

1. After the side skirts are prepped and painted the double sided tape should be applied to the indentation on the inside of the skirt. This surface has to be clean and dry for the tape to properly adhere. Before applying tape wipe the tape surface with the adhesion promoter. When applying tape make sure that tape is smooth and wrinkle free.
2. The surface of the vehicle should also be prepped in the same manner.
3. After applying the tape, pull back approximately one inch of protective covering from the tape on each end. Make sure the film is sticking out.
4. Place the side skirt gently on the vehicle and make sure you have it positioned correctly. You will get ONLY one try so be certain of positioning BEFORE removing film.
5. Once you are certain hold the skirt in position and pull the tabs you created while applying light downward pressure.
6. Continue this taking care not to tear off the tabs by pulling too hard. After all the film is removed apply firm pressure all around to insure the tape has bonded properly.