



# STREET SCENE EQUIPMENT, INC.

950-70780  
1993 - 1997  
NISSAN HARDBODY  
FRONT VALANCE

## INSTALLATION INSTRUCTIONS

**NOTE:** Fit all parts before painting ( See Special Instructions For Paint Prep. ) Parts that have been installed, preped, or painted are not returnable.

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Street Scene Valance	1	Instruction Sheet		
8	1/4-20 X 1" Bolts	16	1/4" Flat Washers	8	1/4" Nyloc Nuts

TOOL LIST
Drill Motor, Drill Bits, 7/16 Socket, Ratchet, 7/16" Wrench, Metric Sockets

1. Remove the OEM valance from bumper.
2. Set the OEM valance on to the Street Scene valance, Mounting side to mounting side and mark mounting holes.
3. Attach with bolts provided ( **NOTE:** you may not require all the bolts in kit ).