



STREET SCENE EQUIPMENT, INC.

950-70799
1982 - 1996
FORD RANGER
ROLL PAN
FIBERGLASS

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See special instructions for paint Prep.) Parts that have been installed, prepped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Roll Pan	1	Instruction Sheet	1	Fiberglass Paint Prep Sheet
				7	# 8 x 3/4" Washer Head Screws

TOOL LIST
Drill Motor, 5/32" Drill Bit, Masking Tape, Tape Measure, Phillips Screwdriver

1. Remove bumper and all attaching brackets.
2. Set the roll pan to body. Center roll pan by inserting a small piece of card board between each end of roll pan and body. Fold cardboard if necessary.
3. Align bottom side of roll pan and tape into position.
4. Open tail gate to full extend and check for clearance between tailgate and roll pan. Adjust roll pan as required.
5. Remove tailgate.
6. Drill a hole in each lower corner through roll pan and into sheet metal. Install remaining screws.