



# STREET SCENE EQUIPMENT, INC.

**950-70802**  
**FORD RANGER**  
**1983 - 1988**  
**FRONT VALANCE**

## INSTALLATION INSTRUCTIONS

**NOTE: Fit all parts before painting ( See Special Instructions For Paint Prep. ) Parts that have been installed, preped, or painted are not returnable.**

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Front Valance	1	Instruction Sheet	1	Street Scene Decal

TOOL LIST	
Miss Sockets, Wrenches, Drill Motor, Drill Bits	

1. Raise the front end of vehicle. Use jack stands to support vehicle.
2. Remove the factory valance from front bumper. Save all fasteners.
3. Set the factory valance on the Street Scene Valance mounting side to mounting side. Mark mounting holes. Drill appropriate size holes.
4. Using fasteners removed in step 2, fasten Street Scene Valance to bumper.