



STREET SCENE EQUIPMENT, INC.

**950-70806
1989 - 1992
FORD RANGER
FRONT VALANCE**

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Front Valance	1	Instruction Sheet		
10	1/4-20 X 3/4" Bolts	20	1/4" Flat Washers	1	Urethane Prep Sheet
10	1/4-20 Lock Nuts				

TOOL LIST
7/16" Wrench, 7/16" Socket, Ratchet, Drill Motor, 5/16" Drill Bit, Clamps

1. Remove the OEM valance from beneath the bumper if so equipped.
2. Set the factory valance mounting side to mounting side to the Street Scene Valance, and using it as a templete mark and drill the mounting holes.
3. If your vehicle was not equipped with a valance, clamp the Street Scene Valance to the bottom side of the bumper. Take time to allign the valance to the bumper. Mark the holes and drill.
4. Use the mounting hardware supplied and mount valance.
5. Follow urethane paint instructions.