



STREET SCENE EQUIPMENT, INC.

**950-70829
2005
FORD F-350 / EXCURSION
BUMPER COVER / VALANCE**

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Bumper Cover	1	Instruction Sheet	6 FT.	3/4" Wide Double Sided Tape
		1	Urethane Prep Sheet	1	Street Scene Decal

TOOL LIST	
NONE	

1. Open hood.
2. Apply the double sided tape to the underside of bumper cover. Make sure the underside is preped the same as the top side before applying. If it is not clean the tape will not stick.
3. Remove the adhesive cover on the double sided tape. Set the bumper cover over the driver's side of bumper and pull to the passenger side " hooking " the edge over the end.