



**950-70832**  
**2003 - 2005**  
**FORD EXPEDITION**  
**S/S FRONT VALANCE**  
**GENERATION 2**

**INSTALLATION INSTRUCTIONS**

**NOTE: Fit all parts before painting ( See Special Instructions For Paint Prep. ) Parts that have been installed, preped, or painted are not returnable.**

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

<b>PARTS LIST</b>					
1	Front Valance	1	Instruction Sheet	1	Street Scene Decal
		1	Urethane Prep Sheet		

<b>TOOL LIST</b>
Torx Set, Screwdriver

1. Remove the OEM valance by removing the fasteners in the front wheel well attaching the valance to the inner fenders. Reach up from underneath above the metal bumper support and pry off the metal retainers securing the bumper cover. Take care not to damage the retainers because they will be re-used in re-assembly.
2. Before installing the SS valance it will be necessary to trim the foam blocks on the metal bumper structure. Refer to the photo on where to trim.



3. Install the SS valance by sliding it into position. Re-install the metal retainers to secure the valance. Install the fasteners securing the valance to the inner fenders.