



STREET SCENE EQUIPMENT, INC.

950-70862
1997 - 2003
FORD F-150 FLARESIDE
&
FORD LIGHTING STEP SIDE
SMOOTH STEPS
4 PIECE SET

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Right Front Step	1	Instruction Sheet	12 FT.	1/2" Two Sided Tape
1	Left Front Step	1	Urethane Prep Sheet	1	Street Scene Decal
1	Right Rear Step	1	Left Rear Step		

TOOL LIST
Channel Lock Pliers, Gloves

REMOVING THE OEM STEPS

NOTE: If you want to save the steps, follow steps 1 & 2. If not go to step 3, Paint all parts prior to installation.

1. Lift vehicle off ground. A hoist will be helpful. If not raise vehicle and support on jack stands.
2. Pinch the retainers together on the underside of step with pliers while pushing up. Do this on all the retainers until the step is released. Remove step from vehicle. Do this on all four steps.
3. Wearing gloves grasp step and pull firmly to remove. Do this on all four steps. The retainers will be damaged and steps cannot be reinstalled.
4. Clean the area thoroughly. Apply the two sided tape to the Street Scene smooth steps. Remove the protective cover on it. Place step on bed and press firmly to adhere tape.