



STREET SCENE EQUIPMENT, INC.

950-76768 BLACK CHROME
950-77768 SATIN FINISH
950-78768 CHROME FINISH
2008
FORD SUPER DUTY
SIDE VENT
SPEED GRILLE INSERTS

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Instruction Sheet			1	Right Side Vent Speed Grille Insert
1	Street Scene Emblem			1	Left Side Vent Speed Grille Insert
1	Care For Grilles			4	Self Locking Retaining Rings

TOOL LIST	
Door Panel Removal Tool Or Equivalent, Side Cut Pliers	

1. Pry off the " F-350 " logo off the front fender being careful not to scratch the paint. Pry off the chrome vent. If any of the eight rectangular retainers remain in the body, remove and install on plastic vent before reinstalling.
2. Set the vent up side down on a table or bench. Carefully pry off the retaining clips that attach the plastic vent grids to the chrome frame. Be carefull not to break off the round studs. You can cut the retaining ring with a pair of side cut pliers.
3. Set the Speed Grille over the studs and attach with the new retaining rings provided. A deep small socket works well to install the retaining ring.
4. Re-install the side vent to front fender by first aligning the mounting clips to the holes in fender and then applying pressure to snap into position.