



STREET SCENE EQUIPMENT, INC.

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
6 PC.	Fender Flare Set	1	Instruction Sheet	27 FT.	1/2" Wide Two Sided Tape
1	Street Scene Decal	1	Urethane Prep Sheet		

TOOL LIST	
# 15 Torx	

1. Remove the factory fender trim. Save all attaching hardware.
2. Thoroughly clean the inner lip of the fender flare. Apply the two sided tape to the lip leave the cover on at this time. Lift off one edge.
3. Install the Street Scene fender flares using the hardware removed in step one. Slide the fender flare into the rocker panel before attaching to body. After the flares are screwed to fender, Grab the tape cover edge and pull the cover off while applying pressure to the flare.

NOTE:

Fender Flares must be painted prior to installation. They can be color matched or clear coated if that look is desired.