



## STREET SCENE EQUIPMENT, INC.

### CONNECTING STREET SCENE SIGNAL® MIRRORS

INSTRUCTIONS FOR PART NUMBERS		
950-15510	950-17520	950-25520
950-15520	950-17526	950-25526
950-15526	950-18520	
950-17530	950-20520	

1. Install Street Scene Signal® Mirror assemblies to door following mirror installation instructions.
2. Before beginning electrical hook-up check the operation of turn signals in the front and rear of vehicle. If any problem exist, repair before installation of Street Scene Signal® mirrors.
3. Remove the door sill plates and kick panels. Remove the lower driver side dash panel.
4. Run the **RED / BLACK** wire on the mirror into the door. Dislodge the rubber boot from between the door and door frame. Guide the wire harness out of the hole vacated by the rubber boot.
5. Pull the rubber boot out from the door frame. Guide the wire through the rubber boot and into the vehicle. Replace the rubber boot between the door and door frame. Guide the wire harness up under the dash and remove any slack in the wire.
6. Do the same on the passenger side. Run the wire across the dash to the right of the steering column.
7. The vehicle's electrical wiring is located under the driver side dash and next to the bottom right side of a large connector. Locate the **LIGHT GREEN WITH YELLOW STRIPE** wire from within the wire bundle. Turn the ignition key so that electrical power is on and activate the driver side turn signal. Probe the wire with the test light to verify that flashing turn signal power is present. Label that wire as "**Driver Side Turn**".
8. Locate the **TAN WITH BLACK STRIPE** wire from within the wire bundle. Activate the passenger side turn signal and probe the wire with the test light to verify that flashing turn signal power is present. Label that wire as "**Passenger Side Turn**".
9. When splicing wire **DO NOT CUT** any wires. Use the quick splice connectores provided.
10. Splice the **RED** wire from the driver side harness into the **LIGHT GREEN WITH YELLOW STRIPE** wire previously labeled "**Driver's Side Turn**".
11. Splice the **RED** wire from the passenger side harness into the **TAN WITH BLACK STRIPE** wire previously labeled "**Passenger Side Turn**".
12. Strip and twist together the ends of the black wires from both harnesses. Crimp them together in the supplied ring connector and ground to a suitable location on the metal framework of the vehicle.
13. Activate each turn signal to verify that the Street Scene Signal® Mirrors are working .
14. Replace all trim parts removed.