



STREET SCENE EQUIPMENT, INC.

950-70330
1997 - 2001
TOYOTA CAMRY
FRONT SPOILER

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Street Scene Spoiler	1	Instruction Sheet		
10 FT.	Double Sided Tape	1	Street Scene Emblem	12	1/4-20 Nyloc Nuts
12	1/4-20 X 1" Bolts	24	1/4" Flat Washers	4	# 6 x 1/2" Self Taping Screws

TOOL LIST	
Miss. Sockets And Ratchet, Drill Motor, Drill Bits	

1. Remove the OEM Spoiler if so equipped.
2. Set the OEM spoiler mounting side face to face with " Street Scene Spoiler ". Mark and drill mounting holes.
3. Use two sided tape on models where no fasteners can be used
4. With the help of a friend install on vehicle.
5. Drill 2 holes on each end and fasten with the self taping screws provided.
6. Fit and prep before painting.
7. Follow urethane painting procedure.