



STREET SCENE EQUIPMENT, INC.

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Tailgate Wing	1	Instruction Sheet	1	Street Scene Decal
10 FT.	1/2" Two Sided Tape	1	Urethane Prep Sheet	2 PKGS	3M Adhesion Promoter

TOOL LIST	
NONE	

NOTE:

CHECK FITMENT OF TAILGATE WING BEFORE PAINTING. FOLLOW URETHANE PAINTING INSTRUCTIONS

1. Remove factory tailgate piece. Clean top edge of tailgate with alcohol.
2. Some grinding of the inside of the wing may need to take place in order to obtain a perfect fit.
3. Clean the back side of wing with alcohol and apply the two sided tape.
4. Set the wing on tailgate and remove the two sided tape. Apply pressure at tape areas.