



STREET SCENE EQUIPMENT, INC.

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Rear Wing	1	Instruction Sheet	3 PKS	Adhesion Promoter Packs
		1	Urethane Prep Sheet	1	Street Scene Decal
10 FT.	1/2" Two Sided Tape			4	Push In Plugs # 18379

TOOL LIST	
Tape Measure, Masking Tape	

NOTE:

Clean Street Scene wing prior to paint. Make sure you clean the backside where the tape will be applied. After you have cleaned the wing clean it again. Follow the paint prep instructions. Pre-fit wing before painting. Sand as necessary for a tight fit.

If vehicle has a factory wing that is being replaced remove OEM wing. The four holes in the deck lid must be plugged using the plugs provided. Push the plugs into the round holes. In the oval holes use a small amount of silicone to seal under the plugs.

1. Clean the backside of wing where the tape will be applied. Apply the Adhesion promoter to the tape legged. Refer to the photo below and apply the two sided tape to wing. Do not remove the backing at this time.

PHOTO



2. Set the wing onto the deck lid. Mark the location at this time. Use masking tape on the deck lid at the wings edges. Remove wing.
3. Lift the corners of the tape backing on the ends.
4. Set the wing onto the deck lid in the position marked in step 2. Grab the corner of the tape backing and pull. Apply pressure to the wing. Do the same on all sides.