



## STREET SCENE EQUIPMENT, INC.

### INSTALLATION INSTRUCTIONS

**Do Not Exceed Lower  
Of Towing Vehicle  
Manufacturer's Ratings**

**OR**

Hitch Type	Max. Gross Trailer Weight ( LBS )	Max. Tongue Weight ( LBS )
Weight Carrying Ball Mount	<b>5000</b>	<b>500</b>

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

#### **Note: Drilling Is Required**

Parts List					
<b>1</b>	Receiver Assembly	<b>1</b>	Instruction Sheet	<b>6</b>	1/2" ID 1/4" Thick Washers
<b>6</b>	1/2" X 1 1/2" Bolts	<b>6</b>	1/2" Nyloc Nuts	<b>1</b>	Hitch Specification Label
<b>6</b>	1/2" ID Flat Washers	<b>1</b>	Street Scene Decal		

Tool List	
3/4" Wrench, 3/4" Socket, Extension, Ratchet, Torque Wench	

Install hitch prior to installing roll pan. It will be necessary to cut a receiver draw bar hole in roll pan. License plate will have to be re-positioned to gain access to hitch. Use Street Scene " Flip-Up " license kit P.N. 950-61100

1. Drop spare tire down.
2. Set hitch up to bottom of frame rails. Install the thick washers on to the bolt. Drop the bolt thru the inside of frame rail into the hole in hitch. Install the flat washer and nut. Install all six bolts and washers before tightening. Push the hitch forward toward the front of truck before tightening.
3. Torque all fasteners to 75 ft. lbs.
4. Crank up spare tire while pushing forward.