

ALL PARTS ARE TO BE INSTALLED BY A CERTIFIED ASE TECHNICIAN



2006-2011 Mercedes CLS Class

2003-2009 Mercedes E Class

Air Suspension Strut

127M-27-FL & FR

Installation Instructions




Before you begin the removal or installation, please read all or the instructions thoroughly!
The warranty will be void if instructions are not followed exactly. Do not work under a vehicle supported by a jack.
Always support the vehicle safety standards.

1. Remove Wheel



2. Disconnect Upper Control Arm.



3. Remove Inner Wheel Well Lining to Locate Electrical Connector.



4. Remove the Sensor Lines From the Bracket.

5. Disconnect Electrical Connector to the Strut.



6. Remove Lower Strut Mounting Bolt.




7. Remove Plastic Shield That Covers The Bolts to the Strut Top Mount.



8. Remove the Top Strut Electrical Connector and Air Line Fitting.



9. Remove the Three Top Mounting Nuts.



10. Remove Strut Assembly From Vehicle.



11. Install In Reverse Order.