

ALL PARTS ARE TO BE INSTALLED BY A CERTIFIED ASE TECHNICIAN



2012-2013 Mercedes-Benz S350

2010-2013 Mercedes-Benz S400

207-2011 Mercedes-Benz S500

2007-2013 Mercedes-Benz S550

207-2013 Mercedes-Benz S600

Electronic Airmatic Suspension

Air Struts Front

136M-28-F

Installation Instructions



Before you begin the removal or installation, please read all or the instructions thoroughly!
The warranty will be void if instructions are not followed exactly. Do not work under a vehicle supported by a jack.
Always support the vehicle safety standards.

1. Raise vehicle on lifting platform.

2. Remove front wheel.

3. Disconnect shock electric cable located in the fender well.



4. Remove the two set screws on the bottom air strut mount.



5. Raise hood and disconnect air supply line to the top of the strut.



6. Remove the three nuts on the upper strut mount to the frame.





BEFORE YOU BEGIN THE REMOVAL OR INSTALLATION, PLEASE READ ALL OF THE INSTRUCTIONS THOROUGHLY!

THE WARRANTY WILL BE VOID IF INSTRUCTIONS ARE NOT FOLLOWED EXACTLY. DO NOT WORK UNDER A VEHICLE SUPPORTED BY A JACK.

ALWAYS SUPPORT THE VEHICLE ON SAFETY STANDS.

7. Separate the upper control arm ball joint from spindle assembly to remove air strut.



8. Install in reverse order.