

## **PRY BAR/SCREWDRIVER HOLDER FOR SERVICE CART**

### **To install the pry bar holder:**

1. Remove the two top side bolts from either side of the top tray or locking top.
2. Place the pry bar/screwdriver holder on the edge of the cart. Match the holes on the cart with the holes on the pry bar/screwdriver holder.
3. Using the screws, washers, and bolts from your original cart, attach the pry bar/screwdriver holder to the side of the cart.