

SumoSprings **Rear**

Suspension Enhancement

GM 1500 Suburban, 1500 Yukon XL
Denali, Escalade, Tahoe excluding XFE series ~ 2x4, 4x4 [2000-present]
SumoSprings Part #SSR-204-40



uninstalled



SSR-204-40 installed on a 2011 Tahoe

© 2011 SumoSprings, Inc. All rights reserved. SumoSprings is a registered trademark of SumoSprings, Inc. Part #SSR-204-40 is a registered trademark of SumoSprings, Inc. All other trademarks are the property of their respective owners.

Installation Instructions

- 1) Park vehicle on level hard surface. Engage emergency brake. Place blocks in front and behind front wheels to prevent rolling. Observe all safety precautions and wear safety glasses.
- 2) Raise rear of vehicle allowing the axle to hang freely. Support the frame using safety jack stands.
- 3) Remove existing factory jounce bumper assembly by grasping it firmly and with a twisting and pulling motion, work it until the jounce bumper pops out of the retaining cup. It can also be pried out of the retaining cup utilizing a large flat blade screwdriver.
- 4) Select a Sumospring from the box and place the top yellow shaped end into the retainer cup from which the factory bump-stop was removed. Then in a twisting and pushing motion insert the Sumospring firmly into the retainer cup where the top edge is held into the retainer cup by the internal tangs as done on the original factory bump-stop.
- 5) If you cannot push the SumoSpring into the cup, place a wooden 2x4 between the end of the SumoSpring and the axle, jack up the vehicle, remove safety jack stands and lower the vehicle with the jack. This will press the SumoSpring into the retaining cup.
- 6) If you have lower the vehicle, repeat steps two through five on the opposite side of the vehicle.
- 7) Jack up vehicle, remove safety jack stands.
- 8) Carefully lower vehicle to the hard surface. Remove the blocks in front and back of the rear wheels.
- 9) Release emergency brake.
- 10) Fill out warranty card and send to SuperSprings. The warranty card is on the reverse side of this page.

Tool List

- Floor Jack 1
- Jack Stands 2
- Short length of wooden 2"x4" 1
- Wheel Blocks 4

Parts List

- SumoSprings Assembly SSR-204-40 2

Important Notice.

- 1) For easy installation please read instructions completely first and have all necessary tools available.
- 2) We recommend that this installation be done by a professional or persons with sound mechanical knowledge.
- 3) SumoSprings are designed to work with the original factory springs only.
- 4) These instructions are meant as a guide for the installation of SumoSprings. SuperSprings International assumes no liability for the actual installation process. Installers should apply common automotive safety practices when raising, lowering and working on vehicles.
- 5) SumoSprings are designed to enhance the vehicles load carrying performance and road handling however it does not authorize (or recommend) loading beyond the manufacturer's GVWR specifications.

To prevent damage to the vehicle and to ensure safety, do not exceed the maximum load recommended by the vehicles manufacturer (GVWR).