

INSTRUCTION SHEET

PRODUCT: 65146 Tajo Kayak Storage System

▪ Page 1 of 1



MOUNTING INSTRUCTIONS

- Locate the wall studs behind the drywall (diagram 1). They are usually 16" apart. A stud finder can be used to find the studs. The Kayak rack must be mounted into a wall stud, as drywall may not be strong enough to hold the weight of the Kayak.
- Position each of the kayak storage racks so that the Kayak is balanced (diagram 2). The closer the Tajo racks are to the end of the Kayak the better.
- Mark the location of the first Kayak rack (A) and drill a 1/8" guide hole (diagram 3). Attach the unit using the supplied screws. The rack is supplied with two spacers. These spacers go between the wall and the bracket. This will help prevent tearing of the foam if mounted on stucco walls. Plastic plugs are supplied so that the unit can be mounted onto a cinderblock or cement wall.
- Measuring from the floor up, mount the second unit (B) so that it is level with the first one (diagram 4).
- Test the racks to insure that they are both secure.
- Mount the Kayak in the cradles so that the Kayak will not fall away from the wall.
- Use the included straps to secure the Kayak to the Tajo Racks (diagram 5).

NOTE: Swagman takes no responsibility for the mounting location. It is up to the installer to insure that the rack is securely install and that the Kayak is secure in the rack.

