

20500

92-07 FORD
ECONOLINE
E150-250 Van
BILLET INSERT



20500

92-07 FORD
ECONOLINE
E150-250 Van
BILLET INSERT

Tools Required:

Phillips Screw Driver
Drill
1/8" Drill Bit

Parts List:

1 - Billet Insert (22 Bars)
6 - #8 x 3/4 Phillips Screws

Read and understand instructions before attempting installation

Note: THIS BILLET GRILLE REPLACES THE ENTIRE GRILLE SHELL. After installation; Opening the hood will require the use of a long screw driver or similar tool to insert in between the bars of the billet grille to release the hood latch.

Step1

Remove the grille shell from the vehicle (**This billet insert replaces the entire factory grille shell**).

Step2

Place the billet insert into the opening. Align the insert so it is flush with the headlight and lower panel. Mark and drill the four lower mounting brackets and fasten to the header panel using the screws provided. Pull the top of the billet grille in and align with the headlights. Drill and fasten the two top brackets to the header panel using the screws.

Step3

Your installation is now complete. *Thank you for purchasing a T-Rex billet grille.*