

**21117/B**  
**14-15 CHEVY**  
**SILVERADO 1500**



**21117/B**  
**14-15 CHEVY**  
**SILVERADO 1500**

## **CHEVY SILVERADO 1500**

### **Billet Series Grille**

**TOOLS REQUIRED:**

Flat/Phillips Screw Drivers

**PARTS LIST:**

(8) 2" Machine Screws

(8) Wing Toggle Clip



### **Step 1**

#### **Grille installation**

Insert the machine screws through the front of the billet grille and through the small black square tabs that are welded to the back side of the billet grilles. Install the wing clip on the end of the screws (Fig 2). Place the billet grille into the factory grille opening, use a flat screwdriver to turn the wing toggle clip so that it inserts into the factory grille behind the honeycomb (Fig 3). Hold the wing toggle clip with a screwdriver to keep it from turning while you tighten the machine screws. Repeat on the second grille. Installation complete.

