

**21316**  
**04-14 GMC**  
**SAVANA VAN**



**21316**  
**04-14 GMC**  
**SAVANA VAN**

## **04-14 GMC SAVANA VAN**

### **Billet Grille Overlay w/ Logo Opening**

#### **TOOLS REQUIRED:**

8mm Socket and Ratchet  
Flathead Screwdriver

#### **PARTS LIST**

(4) 1 1/2" Machine Screws  
(4) 1/2" "L" Brackets  
(4) 6/32 Nylon Lock Nuts  
(1) Billet Grille

#### **Step 1**

Remove the radiator top cover. There are several plastic pop clips that you can pry up with a flathead screwdriver. Set the radiator top cover to the side.

#### **Step 2**

Take the billet grille and insert it into the opening in the factory grille shell. (Fig 1)

#### **Step 3**

Take the four 1 1/2" machine screws and insert them through the billet bars and the small square brackets with a hole in the center that are welded onto the backside of the billet grille (Fig 2). Install the four 1/2" L-Brackets and 6/32" nylon lock nuts on the screws and tighten with a 8mm socket (Fig 3). Reinstall the radiator cover. Installation complete.

