

**21573**  
**21573B**  
**13-14 FORD**  
**F-150**



**21573**  
**21573B**  
**13-14 FORD**  
**F-150**

**FORD F-150**  
**Billet Grille Overlay**  
Install time: 25 Mins.

**TOOLS REQUIRED:**

Plastic Prybar  
Die Grinder  
Drill & 1/8 Drillbit

**PARTS LIST:**

(4) Billet Grilles  
(8) L-Brackets  
(8) 1.5 (6Head) Screws  
(8) U-Nuts

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS  
BEFORE ATTEMPTING INSTALLATION.

**Step 1 Remove Factory Grille Shell**

- Insert the U-Nuts through the L-Brackets with the Holes. (Fig. 1)
  - Place the #8 Screw through the Brackets that are on the Billet Grille. (Fig. 2)
  - From behind the Grille, Thread the 1.5 Screw through the L-Bracket so it Latches onto the Factory Grille. (Fig. 3)
- Repeat for remaining Screws.

**INSTALLATION COMPLETE**

