

07-08 TOYOTA





<u>07-08 TOYOTAYARIS</u>

Tools Required:

Phillips / Slotted Screwdrivers 8mm, 10mm Socket

Hardware / Parts Included:

Billet Insert
2" Flange Brackets

4 U Nuts 4 1 ¼″ #8 6 Head Screws

Read and understand instructions before attempting installation

Step 1

1

Remove the 10mm bolts securing the lower motor skid plate to access the rear of the grille.



Step 2

Place the provided U Nuts onto the flange brackets. Place the upper grille in place in the factory grill opening. Place the #8 6 head screws through the billet bars and through the four welded brackets with holes in them that re on the backside of the <u>billet grille</u>. While holding the grille in place, place the four flange brackets with the u nuts on the backside of the factory grille and tighten the screws. (Fig 1)

If you purchased the lower grille; install now!

Step 3

Re-install the lower skid plate assembly onto the vehicle using the factory Hardware. *Thank you for purchasing your T-Rex billet grille.* 07/01/08