

25179

01-14 GMC

Yukon Denali

Sierra C3

AIR DAM BILLET

With Out Tow Hooks



25179

01-14 GMC

Yukon Denali

Sierra C3

AIR DAM BILLET

With Out Tow Hooks

Tools Required:

Phillip Screw Driver

Parts List:

1 - Air Dam Insert (9 Bars)

4 - #8 x 3/4 Phillip Screws

4 - #8 Flat Nuts

Read and understand instructions before attempting installation

Step 1.

THE FACTORY TOW HOOKS MUST BE REMOVED FROM THE VEHICLE FOR THIS BUMPER BILLET INSERT. Remove the factory plastic insert if the vehicle has one.

Step2

Center the billet in the air dam opening. There is a hole in each tab welded to the back of the insert where they meet the air dam opening. Align the billet with the holes and fasten with a screw and clip at each bracket. Tighten the four screws.

Step3

Installation complete. *Thank you for purchasing your T-Rex billet grille.*