

**25458**  
**25458B**  
**13-15 DODGE**  
**RAM 1500**



**25458**  
**25458B**  
**13-15 DODGE**  
**RAM 1500**

---

## **13-15 DODGE RAM 1500**

**Billet Bumper**  
Install time: 20 Mins.

**TOOLS REQUIRED:**

3/16 Drillbit + Drill  
Screwdriver

**PARTS LIST:**

(1) Billet Grille  
(2) #8 Screws  
(2) Flatnuts

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS  
BEFORE ATTEMPTING INSTALLATION.

Remove either the Splash Guard or the Plastic Cover along the Top of the Grille to reach behind the Bumper Opening.

- Place the Grille onto the Bumper Opening and Look at where the Brackets on the Grille is.
  - With the 3/16 Drillbit, Drill through the Brackets. (Fig. 1)
  - Place a #8 Screw through the Bracket and Place a Flatwasher Behind the Bumper Opening.
- Repeat for remaining Bracket.

**INSTALLATION COMPLETE**

