

25518
10-12 FORD
MUSTANG



25518
10-12 FORD
MUSTANG

10-12 FORD MUSTANG **Bumper Billet Base Models**

TOOLS REQUIRED:

Socket and Ratchet Set
Flat/Phillips Screwdrivers

PARTS LIST:

(2) 2" Machine Screws
(2) 6/32" Nylon Lock Nuts
(2) 1/2" L-Brackets
(1) Bumper Billet



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model.

Step 1 Top Radiator Cover Removal

First you will remove the top radiator cover from the vehicle. There are 8 plastic pop clips on the radiator cover that need to be removed with a flat screwdriver by prying the head upward (Fig 1). Now you can remove the radiator cover. This will give you access to the rear of the factory bumper.

Step 2 Bumper Billet Installation

With the radiator cover removed, place the bumper billet into the factory bumper opening (Fig 2). Now take the two 2" machine screws and insert them through the billet bars and the small square tabs with the hole in the center that are welded onto the backside of the bumper billet. Reach down through the top where the radiator cover was removed and place the two 1/2" L-Brackets over the 2" screws. The L-Brackets will latch around the plastic in the factory bumper. Install the two 6/32" nylon lock nuts on top of the L-Brackets and tighten (Fig 3). Reinstall the radiator cover. Installation complete.

