

# 51032/54032

## 14-15 CHEVROLET CAMARO RS



# 51032/54032

## 14-15 CHEVROLET CAMARO RS

## **CHEVROLET CAMARO RS**

### **Upper Class Grille**

#### **TOOLS REQUIRED:**

Socket and Ratchet Set  
Flat/Phillips Screwdrivers

#### **PARTS LIST**

- (1) grille
- (4) 6/32" Nylon Lock Nuts
- (4) 2" Bone Bracket
- (4) 10/32" Washers
- (4) 2" Black PVC Tubing



### **Step 1 Radiator Cover Removal & Grille Installation**

Open the hood on the vehicle. Now remove the four 10mm bolts from the top of the radiator cover plate (Fig 1). Now remove six plastic pop clips that hold the radiator cover and the bumper cover together (Fig 2). Now remove the radiator cover plate (Fig 3) this will give you access to the rear of the factory grill. Slide the four pieces of black pvc tubing onto the threaded studs that are welded to the back of the mesh grille. Insert the mesh grille onto the factory grill opening (Fig 4). Take the two bone brackets and reach down behind the mesh grille and insert them onto the threaded studs on the back of the mesh grille (Fig 5). Slide the washers over the threaded studs along with the nylon lock nuts and tighten. Reinstall the radiator cover. Installation complete. Thank you for purchasing a T-REX Grille.



Fig 1



Fig 2



Fig 3



Fig 4



Fig 5